

OPERATING INSTRUCTIONS:

CORD TILT (STANDARD)

Pull cord down to rotate the slats open. Pull the opposite cord to rotate the slats closed.

WAND TILT

Twist the wand to rotate the slats to the desired angle.

RECHARGEABLE MOTORIZED TILT

Control a single blind or group of blinds with one remote. See separate Programming Instructions for additional set up information.

CORD LIFT (STANDARD)

Pull the lift cords straight down to raise and lock the raised slats into position. Pull the lift cords toward the center of the blind to unlock and lower. It may sometimes be necessary to lift up on the bottomrail to release the cordlock to lower the blind. *Keep slats tilted open while raising and lowering.*



CORDLESS LIFT

Raise and lower the blind by gently pulling or pushing on the bottomrail

LIFT & LOCK CORDLESS

Press the bottomrail button to easily operate the blind, then release the button to lock in position.

MOUNTING BRACKETS: Inside Mount



The box style mounting brackets are designed to work in all possible mounting applications. (Fig. 1) Indicates which screw holes to use for each option. Mount brackets as shown below.

Always use all brackets supplied. Blinds over 48" wide must have one support bracket, and blinds over 96" wide must have two.

Space the support brackets as evenly as possible between the two end brackets. There should be no more than 48" between any two brackets.

IMPORTANT: Avoid positioning support brackets in line with blinds ladders or tapes.

Use two screws to attach each support bracket. Locate the screws diagonally. Make sure the support bracket's top and back surfaces are aligned with the top and back surfaces of the two installation brackets. (Fig. 2) Be sure to mount all brackets parallel to one another.

BRACKETS REQUIRED



All blinds require two end brackets.

All two-on-one headrail's receive one center support bracket.

Support brackets for two-on-one headrail's should be placed between panels.

Shade Width	# of Support Brackets
Over 48"	1
Over 96"	2

MOUNTING BRACKETS: Outside Mount



1. Mark where to attach the two installation brackets. Hold the blinds up to the window in the position where you want it installed.


2. With the blind centered and level, mark the surface 1/4" past each end of the headrail. (Fig. 3)

3. Attach the installation brackets to the wall or molding with two screws.

4. Position the screw diagonally.

NOTE: Spacers are necessary with 2 1/2" blinds only. (Fig. 4) See "Spacer Blocks" section for more information.

SPACER BLOCK






Spacer blocks are used to provide extra depth clearance for a horizontal blind. Certain applications require the use of spacer blocks.

The slat on a 2 1/2" blind extends beyond the back of the headrail. Spacer blocks must be used for all 2 1/2" outside mount applications.

In these situations, use one spacer block for each installation bracket. (Fig. 5)

NOTE: When mounting blinds on a French Door or on a window with molding, we recommend using one spacer block per bracket for 2" blinds, and two spacer blocks per bracket for 2 1/2" blinds.

VALANCE ATTACHMENT



Your blinds will be shipped with either valance clips or magnets for attaching the valance.

IF USING VALANCE CLIPS: Install one clip on each end and space any other evenly in between; no more than 48" apart.

1. **Important:** Install the valance clips before mounting the headrail. (Fig. 6) (Fig. 7)

2. After mounting the headrail, attach the valance.

3. Simply snap the valance into the valance clips.


IF USING MAGNETS

Magnets are already attached to the valance. Place the valance against the headrail. (Fig. 8)

OUTSIDE MOUNT ALUMINUM BLINDS

Returns are attached to the end of the bracket using self-adhesive pads. Returns are not available on 2" Aluminum blinds.


INSTALL THE HEADRAIL



1. Position the headrail in the box brackets as shown. (Fig. 9)
2. Swing the covers down and snap them closed.

IMPORTANT: Attach the valance clips before installing the headrail. See the “Valance Attachment” section (Fig. 6-7) for more information.


TILT WAND ATTACHMENT



NOTE: Tilt wand attachment not applicable with cord tilt or rechargeable motorized tilt.

1. Attach the wand tip over the end of the tilter hook.
2. Slide the clear cover down to hold the wand in place. (Fig. 10)


HOLD DOWN BRACKETS



Fits into the pre-drilled hole in the bottom rail to secure the bottom rail in place
(Generally used on doors.) (Fig. 11)

NOTE: Not available with Lift & Lock. Aluminum blinds have pre-molded hold down pins.

CHILD SAFE



An important consideration in any blind installation is child safety. To prevent serious injuries or strangulations, all cords must be kept out of the reach of children. Cord cleats or other methods of keeping the cords from hanging within reach of a child should be utilized. (Fig. 12)
Horizontal blinds also include breakaway tassels that will separate and prevent the lift cords from traveling backwards through the cordlock.

⚠ WARNING:

Young children can become entangled and strangle in cords. Keep all cords out of the reach of children.

CARE AND CLEANING

DUSTING

Like all wood furnishings, wood blinds should be dusted regularly to keep them looking new. Use a soft, clean cloth, dusting mitt, or chemically treated dust cloth. Lower the blinds to its full length, tilt the slats almost all the way down and dust. Then tilt the slats almost all the way up and dust. (Not fully closing the slats allows dusting where the slats overlap.)

VACUUMING

Blinds may also be cleaned by vacuuming them with the brush attachment of a vacuum cleaner; tilting the blinds open and described in the previous section.

DAMP CLEANING

Another way to clean blinds is simply by wiping them with a soft, damp rag.

IMPORTANT: Ultrasonic cleaning and bleach wipes/cleaners are not recommended.